The Above-Bed Art Hanging Sheet

Size your canvas precisely and mount it securely on a hidden ledge.

Eliminate the guesswork from your bedroom styling. Find the exact width for your mattress and hang it perfectly level every time.



Key Measurements

2/3
headboard width for balanced scale

8–10 in
over headboard clearing sleeping pillows

45°
French cleat for flush mounting

Half
the weight using shatterproof acrylic

Bumpers hold it square

Press small felt pads into the lower back corners. Because the top cleat pushes the canvas out slightly, these bumpers match the upper depth perfectly.

French Cleat Hanging Sequence

1. **Mark the center** Mark the exact center of your headboard on the wall.
2. **Draw level line** Draw a perfectly level pencil line at your desired height.
3. **Locate wall studs** Locate and mark the structural wall studs.
4. **Mount wall cleat** Screw the upward-facing wall cleat into the anchors.
5. **Prep the frame** Attach the downward-facing cleat to the frame.
6. **Drop into place** Drop the canvas straight down into place.

Canvas Width By Bed Size

Find your row: **Your mattress size**

Your mattress size	Your pick	Why
Twin (38 inches)	26 inch canvas	Anchors the narrow sleeping area
Full (54 inches)	36 inch canvas	Balances standard bedroom furniture
Queen (60 inches)	40 inch canvas	Leaves room for bedside lamps
King (76 inches)	50 inch canvas	Or hang a spaced diptych

Bedroom Wall Checks

- ○ Measure starting height from the mattress if lacking a traditional headboard.
- ○ Account for thick Euro shams that easily obscure the bottom edge.
- ○ Find solid wood framing behind plaster before drilling to anchor cleats.
- ○ Apply firm downward pressure on the wall strip to test integrity.
- ○ Check the packaging for the specific weight rating of drywall anchors.

Room Dimensions & Notes

Enjoy your beautifully anchored sleeping space and perfectly leveled bedroom artwork!