The Bathroom Tub Fit Checklist

Measure your body and space to find your perfect soaking tub.

Confidently match flat-floor length to your legs, soaking depth to the overflow, and tub capacity to your water heater. Take these numbers to the showroom to select a freestanding tub that fits beautifully.



Key Tub Measurements

15+ in
Minimum depth to overflow for adults

70%
Usable hot water from heater capacity

15-20 gal
Water displaced by an adult body

4+ in
Minimum wall clearance for a mop

The Warm-Rinse Sequence

1. **Activate hand shower** Divert water to the wand and wait for the stream to turn fully hot.
2. **Spray interior walls** Slowly trace the sloped backrest and flat floor to warm the chilled material.
3. **Fill the basin** Switch the diverter back to the main spout and fill to your desired depth.

Secure the Freestanding Base

Ask your plumber to apply a thick bead of heavy-duty silicone adhesive beneath the hidden base to anchor the fixture securely to your floor tile.

Find Your Flat Floor Fit

Find your row: **Your floor-sit length**

Your floor-sit length	Your pick	Why
Up to 38 inches	39-inch flat floor	Requires 59-inch overall tub length
Up to 43 inches	44-inch flat floor	Requires 65-inch overall tub length
Up to 48 inches	49-inch flat floor	Requires 71-inch overall tub length

Showroom & Site Checks

- [ ] Ask: depth to overflow from interior floor to round drain cover.
- [ ] Sit back-to-wall first to find your natural reclining baseline.
- [ ] Match spout to rim combined thickness so water clears the edge.
- [ ] Specify an end-drain configuration if bathing solo for uninterrupted legroom.
- [ ] Finalize tub and floor-mount rough-in positions before laying the subfloor.
- [ ] Ask a professional where to find your floor's structural load rating.

Showroom Notes & Measurements

Enjoy your perfectly proportioned, deeply restorative spa experience right at home!