Renter's Shower Caddy Install Sheet

Mount a heavy-duty adhesive caddy and remove it spotless at move-out.

Confidently organize your shower with damage-free results your landlord will love. This step-by-step checklist ensures a permanent hold and a perfectly clean removal.



Key Specifications

11 in
Between baskets for pump bottles

304 grade
Stainless steel to prevent rust

24 hours
Cure time before adding weight

10 minutes
Air dry time after degreasing

3 minutes
Hairdryer heat to soften glue

Center Pad On One Tile

Keep the entire sticky footprint on the flat, glazed face of a single tile. Avoiding grout lines prevents moisture from sneaking in and deteriorating the adhesive.

Install & Move-Out Sequence

1. **Tile Degrease** Scrub with dish soap, wipe with rubbing alcohol, and let air dry completely.
2. **Mark And Press** Draw guide dots with washable marker, press pad outward with credit card.
3. **Curing Phase** Leave baskets empty and avoid steamy showers until the bond sets fully.
4. **Floss Removal** Aim a high-heat hairdryer, then saw through softened glue with dental floss.
5. **Final Clean** Dissolve leftover residue with rubbing alcohol and snap a move-out photo.

Minimum Basket Depth Guide

Find your row: **Your Storage Need**

Your Storage Need	Your pick	Why
Bar soap and razors	2 inches	Top tier organization
Standard shampoo bottles	3 inches	Middle tier storage
Heavy liter pump bottles	4 inches	Bottom tier stability

Shower Pre-Checks

- ◯ Hold a level to verify the corner meets at a right angle.
- ◯ Choose the back corner opposite the direct spray of the showerhead.
- ◯ Check that extra-wide adhesive pads fit entirely within your tile borders.
- ◯ Confirm your heaviest liter bottles fit on the lowest basket.

Installation Notes

Enjoy your beautifully organized shower without risking a single dime of your deposit!