Hotel-Style Double Shower Curtain

Measure, mount, and hang your custom floor-to-ceiling drapery.

Achieve a seamless, luxurious bathroom upgrade with precise math instead of guesswork. Use this sheet to confidently mount your hardware and size your textiles perfectly.



Key Measurements & Specs

2 inches
Rod placement below the ceiling

2 panels
Required for luxurious 2x fullness

1 inch
Outer hem clearance off floor

54-72 inches
Standard tub width for panels

6 months
When to replace clear liner

Train Your Fabric Folds

Dress the fabric by hand immediately after hanging. Gently pinch pleats from top to bottom so heavy waffle-weave drapes in uniform columns rather than flaring out.

Panel Length & Rod Height

Find your row: **Your ceiling height**

Your ceiling height	Your pick	Why
8-foot (96 in)	84-in panel, 94-in rod	Fits standard eight-foot rooms
9-foot (108 in)	96-in panel, 106-in rod	Fits taller nine-foot ceilings
10-foot (120 in)	108-in panel, 118-in rod	Fits grand ten-foot ceilings

Pre-Installation Checklist

- ○ Total ceiling height measured straight from the finished floor tile.
- ○ Width of the tub opening from wall to wall.
- ○ Desired ring drop length from the rod down to curtain hole.

Mounting & Hanging Steps

1. **Secure the Brackets** Anchor mounting plates into drywall using heavy-duty toggle bolts to support wet and dry layers safely.
2. **Hang Inner Liner** Place a clear waterproof liner on the hidden inner rod to protect your decorative textiles.
3. **Tuck the Liner** Keep the liner's weighted bottom edge firmly inside the tub rim to direct water down the drain.
4. **Hang Outer Panels** Use separate, smooth-gliding brass rings for outer panels so they remain untouched by daily showers.

Project Notes

Enjoy your beautifully tailored, high-end bathroom retreat!