

Pro Closet Spacing Cheat Sheet

Maximize your entryway storage with perfectly measured rods and shelves.

Stop guessing where to hang your hardware and use this exact spacing guide. Tailor these pro measurements to your own coats, shoes, and bins for a perfectly organized entryway.

● Standard Clearances

68 in

Standard upper rod height

36 in

Standard lower rod height

40-50 in

Vertical drop for long coats

15 degrees

Pitch for angled shoe shelves

8 in

Spacing between angled shoe tiers

Min 14 in

Floor clearance for winter boots

2-3 in

Allowance for hanger hardware drop

Light the Lower Zones

Install motion-activated LED strip lights beneath the middle shelf to illuminate deep shadows without complicated hardwiring.



● Pro Spacing Placements

- 1 Set-back lower rod** Push the lower rod 4 to 6 inches back, adjusting for your thickest winter coat sleeves.
- 2 14-inch seasonal bins** Set the top shelf 15 to 16 inches below the ceiling; adjust for your exact basket height.
- 3 Tension rod shoe stop** Place the tension rod exactly 1 inch above the shelf to catch your specific footwear heel blocks.
- 4 Door-back mail catch** Mount the organizer within the top 60 inches of the door to clear your bulky hanging jackets.

- **Measure Before Drilling**

- ☐ Vertical length of your longest winter coat
- ☐ Width of your widest pair of winter boots
- ☐ Exact height of your preferred seasonal storage bins
- ☐ Maximum weight rating on your door organizer's packaging

● Door Hardware Guide

Find your row: **Door core material**

Door core material	Your pick	Why
Hollow Core	Toggle Bolt	Distributes the load safely
Solid Wood	Wood Screw	Supports heavy brass fixtures
Metal Clad	Self-Tapping	Bites into metal securely

● My Closet Dimensions

Enjoy your beautifully organized entryway that fits your family's daily routine perfectly!