Entryway Mirror Hanging Sheet

Calculate exact proportions and mount heavy glass perfectly flat.

Eliminate installation guesswork by calculating your exact mirror proportions. Follow this sequence to guarantee perfect placement on your first attempt.



Your Key Proportions

Eye height
Baseline center point from floor

2/3
Of the console table width

8 in
Vertical gap above the console

French cleat
Behind upper back of mirror

Spacer strip
At bottom back edge

Lamp
Beside the glass, overlapping slightly

Hidden Bottom Spacer

Attach a wood strip or stacked heavy-duty felt pads behind the lower edge to match the cleat's thickness, keeping the heavy glass perfectly parallel to the wall.

6-Step Install Sequence

1. **Record Eye Level** Measure from the floor to establish the baseline center point for the mirror reflection.
2. **Calculate Dimensions** Input console width and height to calculate proportional glass dimensions required for balance.
3. **Mark Vertical Gap** Mark the calculated gap on the wall using a light pencil and bubble level.
4. **Transfer Screw Height** Transfer the generated cleat screw height directly to your wall studs for maximum support.
5. **Secure Wall Bracket** Drive heavy-duty wood screws perfectly flush into studs to attach the lower interlocking cleat.
6. **Mount The Mirror** Carefully slide the upper bracket down onto the wall cleat until they lock firmly.

Measurements By Console Width

Find your row: **Console Width**

Console Width	Your pick	Why
36 to 40 in	24 to 26 in wide	64 in cleat screw height
42 to 46 in	28 to 30 in wide	64 in cleat screw height
48 to 52 in	32 to 34 in wide	66 in cleat screw height
54 to 58 in	36 to 38 in wide	66 in cleat screw height
60 to 66 in	40 to 44 in wide	68 in cleat screw height
72 to 80 in	48 to 52 in wide	68 in cleat screw height

Reflection & Styling Checks

- ○ Verify opposite reflection frames a sunny window, plant, or vibrant art.
- ○ Check reflection from living room sofa to avoid framing private spaces.
- ○ Ensure the console table is stable and won't bump the mirror.
- ○ Tuck the table lamp cord out of sight using clear zip ties.
- ○ Keep central decor low to preserve the unobstructed lower third.

My Entryway Measurements

Enjoy your beautifully balanced and perfectly secure new entryway vignette!