

Laundry Cabinet Dimensions Guide

Map out custom built-ins and hidden storage for a clutter-free utility space.

Transform your laundry routine with clever concealed pull-outs and ergonomic workspaces. Use these standard measurements to plan cabinetry that perfectly fits your appliances.

● Essential Clearances & Pull-Outs

Min 18x14 in

Fold-out iron drawer clearance

3.5 in deep

Hidden toe-kick drawer capacity

4 in gap

Magnetic lint bin wall clearance

Min 12 in vertical

Detergent tap jars shelf gap

1 in air gap

Waterfall folding top machine clearance

6 in back, 1 in sides

Front-loader appliance breathing room

25.5 in deep, 39-40 in high

Continuous folding counter dimensions

Prevent Sagging and Swelling

Construct upper cabinets from exterior-grade plywood. It resists plumbing leaks, high humidity, and securely anchors heavy fold-out ironing hardware for decades of daily use.



● **Standard Frame Depths & Heights**

Find your row: **Cabinet component**

Cabinet component	Your pick	Why
Lower base cabinets	24 in deep	Needs 36 in aisle space
Upper wall cabinets	12-14 in deep	Mount 18 in above counter
Tall utility pantry	84-90 in high	Check door swing clearance
Recessed toe-kick	4.5 in high	Set 3 in back
Open floating shelves	10-12 in deep	Align with upper cabinets

● **Final Spatial Verification**

- ☐ Measure appliance width with doors fully open for hinge clearance.
- ☐ Confirm rigid vent hose routing depth against your back wall.
- ☐ Verify the floor slope with a long level before building.
- ☐ Check ceiling height to ensure tall cabinets clear crown molding.
- ☐ Ensure detergent drawers open fully without scraping the wood counter.

● **Smart Storage & Hardware Details**

- ☐ Consult an electrician for a dedicated iron cabinet outlet.
- ☐ Check bracket packaging for weight ratings to support heavy jars.
- ☐ Add shallow pull-out drying racks directly below upper cabinets.
- ☐ Position solid stainless spigots slightly over the open shelf edge.
- ☐ Line the appliance cavity side walls with dense acoustic foam.
- ☐ Strap heavy utility lines securely to the back drywall.
- ☐ Place thick anti-vibration rubber pads under adjustable machine feet.

● **Project Notes & Measurements**

Enjoy your beautifully organized, highly functional new laundry space!