Master Bedroom Layout Clearance Sheet

Map your perfect sleeping zone with exact measurements and the two-spot tape test.

Visualizing your precise footprint prevents cramped walkways and ensures a calming energy. Use this guide to perfectly place your bed, rug, and nightstands before moving heavy furniture.



Key Layout Clearances

2/3 under the bed
Rug placement to aesthetically anchor room

Level to +2 in.
Mattress-height tables for ergonomic reaching

36 in. pull
Dresser clearance for comfortable standing

1/2 inch
Baseboard trim to measure space from

Do the 2 a.m. walk

Navigate your taped path in complete darkness from the mattress edge to the doorway to definitively confirm your physical spacing is genuinely safe and completely obstacle-free.

The Two-Spot Tape Test

1. **Tape both spots first** Outline your exact bed frame and headboard footprint in the two most viable locations.
2. **Include the nightstands** Tape bedside tables simultaneously to accurately judge the entire functional sleeping zone.
3. **Check narrowest points** Measure between the foot of the bed and the nearest wall or heavy furniture piece.
4. **Verify door swings** Ensure heavy furniture stays completely clear of the maximum swinging arc of all doors.

Your Clearance Zones

Find your row: **Your layout zone**

Your layout zone	Your pick	Why
Sleeping side walkway	30 inches minimum	Prevents cramped nighttime navigation
Entry door swing	12-18 in. past arc	Avoids damaging furniture upon entry
Closet door swing	24 inches minimum	Ensures you can view wardrobe easily

Check Before Moving Furniture

- ○ Measure total mattress height from floor to the highest fluffed point.
- ○ Survey wall behind taped nightstand zones for safe electrical outlet access.
- ○ Start rug's top edge just in front of nightstands, leaving bare floor.

Layout Notes & Measurements

Enjoy transforming your cramped sleeping area into a highly functional, deeply relaxing master retreat.