# Hidden Dimension Cheat Sheet

## Exact framing depths and clearances for a small luxury bathroom.

Transform a compact bathroom into a high-end spa with precise layout measurements. Hand these verified numbers to your contractor to build space-saving luxury features.



### Key Framing & Clearances

**2x6 framing**
In-wall carrier depth for toilet

**10 inches**
Floor gap beneath floating vanity

**14 inches**
Width for hidden stud niche

**1/16 inch**
Color-matched grout line width

**3000K**
Flush LED channel color temperature

**Max 22 inches**
Compact toilet projection from wall

**Min 36 inches**
Width for fixed glass panel

**1/4 inch per foot**
Shower floor slope to drain

*Protect the Subfloor*

*Treat the floor as a wet room by extending the waterproofing membrane at least three feet beyond the curbless shower opening to prevent hidden water damage.*

## Find Your Style Palette

Find your row: **Your Desired Vibe**

| Your Desired Vibe | Your pick | Why |
|---|---|---|
| **Sophisticated and masculine** | Dark slate and walnut | Upscale with matte black fixtures |
| **Seamless and earthy** | Warm plaster and brass | Develops a beautiful natural patina |
| **Playful and monolithic** | Matching terrazzo surfaces | Lets a stark white vanity pop |
| **Graphic and punchy** | Crisp white subway tile | Contrasts stark matte black hardware |
| **Calming spa energy** | Soft sage and fluted oak | Adds essential tactile warmth |

## Pre-Drywall Checks

- [ ] Verify the 3-inch waste line navigates joists without structural compromise.
- [ ] Ensure sink plumbing routes backward to keep vanity underside clear.
- [ ] Confirm flush plate height aligns comfortably with the vanity counter.
- [ ] Add solid wood blocking for the carrier and glass partition.
- [ ] Check that the niche sill pitches forward for proper drainage.

## Project Notes & Measurements

Enjoy your beautifully balanced, clutter-free luxury retreat!