10-Minute Sconce Setup Guide

Exact placement measurements and parts for wireless wall lights

Skip the expensive electrician entirely. Confidently measure, attach, and light beautifully proportioned fixtures perfectly suited to your space.



Key Measurements & Settings

60 inches
from floor (8-foot ceiling)

8 inches
from art frame to sconce base

2700K
warm glow for residential atmosphere

6 inches
inward from console outer edges

50 percent
brightness to maximize battery lifespan

30 seconds
firm pressure on mounting bracket

Let the adhesive cure

Always wait a full hour before attaching any weight to the bracket. Rushing this step can cause your heavy brass fixture to slide down the wall.

The Wire-Free Installation

1. **Map the wall space** Mark center points lightly with a pencil and calculate your vertical and horizontal coordinates.
2. **Mount adhesive wall plate** Press firmly against the drywall and verify alignment with a small torpedo level.
3. **Install rechargeable LED bulb** Twist the fully charged self-powered unit into the socket to instantly illuminate the space.
4. **Layer the ambient glow** Combine the new fixtures with existing overhead pendants to eliminate harsh isolated shadows.

Sconce Count & Spacing

Find your row: **Total room width**

Total room width	Your pick	Why
Under 10 feet	1 accent sconce	Centered on the wall
10 to 15 feet	2 sconces	Spaced 72 inches apart
Over 15 feet	3 sconces	Spaced 60 inches apart

Architecture & Styling Checks

- [ ] Add 2 inches of height per foot of ceiling above 9ft.
- [ ] Verify the new elevation against door frames for visual consistency.
- [ ] Ensure the fixture sits tightly within vertical boundaries of your furniture.
- [ ] Confirm all bulbs in the sightline match the exact color temperature.
- [ ] Set up a decorative charging bowl on the console table below.

Room Measurements & Notes

Enjoy your beautifully balanced, warm, and wire-free lighting setup!