Stacked Laundry Rough-In Sheet

Grab the exact wall measurements to push your machines perfectly flush.

Achieving a seamless, built-in look requires moving bulky utilities out of the way. Use these exact measurements to place your plumbing, venting, and blocking before the drywall goes up!



Clearances & Heights

42 in
Valve box on side wall

36-42 in
Standpipe in shared side box

34 in
240V outlet offset on back

Baseboard level
Vent box on center back

Min 32 in
Closet width for 27-in machines

Min 6 in
Shelf clearance above the dryer

Min 4 in
Side gap for valve access

Up to 6 in
Depth gained with recessed vent

One lever, both valves

Install a single-lever master shutoff valve in your side-wall box. It lets you instantly cut both hot and cold water in an emergency without reaching behind the appliances.

Adapting to Your Space

Find your row: **Your setup**

Your setup	Your pick	Why
Second-floor laundry	Floor pan with drain	Must be 2 inches wider than machines
Tight closet depth	Slim periscope duct	Maintains safe airflow flush against wall
Heavy shelf items	3/4-inch plywood blocking	Solid anchoring anywhere between wall studs
Stacking appliances	Approved stacking kit	Prevents dangerous high-speed spin vibrations

Measure Before You Frame

- ○ Measure the machine door swing radius against the side walls.
- ○ Check the closet door hinge intrusion when fully open.
- ○ Verify the 120-volt washing machine outlet is easily accessible.
- ○ Locate the dryer's specific electrical cord exit point on diagrams.
- ○ Find the approved stacking kit and weight rating for your models.

Flush Installation Checks

- ☐ Upgrade to stainless steel braided supply hoses.
- ☐ Secure corrugated drain hose with a heavy-duty zip tie.
- ☐ Apply manufacturer foam dampening strips to the stacking bracket.
- ☐ Level the washer perfectly with a heavy-duty torpedo level.
- ☐ Slide dense rubber vibration pads under washing machine feet.
- ☐ Tape thick power cords to machine backs with painter's tape.
- ☐ Test periscope duct connections for subtle air leaks.
- ☐ Finish drywall with moisture-resistant primer and high-gloss trim paint.

Project Notes

Enjoy your beautifully flush, perfectly organized new laundry space!